

Direct Glue Wallcovering Installation Guidelines

Please inspect installation after three drops of the fabric. If there are any issues, please stop installation and inform your Teknion Textiles representative or customer service at 1-855-TEK-TEXTL (1-855-835-8395). Teknion Textiles cannot accept any claims on labor or material of more than three lengths (9 linear yards or 8.2 meters) that have been cut and installed.

Inspection

- Confirm all rolls are the correct pattern and color.

Storage

- Be sure to store fabric in a clean, dry environment.
- Do not store rolls standing on end.

Wall/Space Preparation

- Wall surfaces must be completely smooth, clean and dry.
- A high quality white wall primer should be used on all wall surfaces prior to installation. Walls must be a uniform color.
- Finished lighting should be in place before hanging fabric.

Cutting

- Fabrics should have no less than 2-3" (5-8 cm) cut from each selvedge with a straight-edge and sharp knife blade. A new blade is recommended for each cut.
- "Top" should be marked at the time of cutting on each strip. (Note: on light colored fabrics, be sure to use a method that won't telegraph through to the face, avoiding too much pencil or ink.)
- Fabric can be table cut or doublecut on the wall at the discretion of the hanger.

Adhesive

- Use a high quality, heavy-duty, clear, vinyl adhesive.
- Do not dilute the adhesive.
- Avoid getting any adhesive on the face of the fabric, but if it does happen allow it to dry and clean with a dry brush or follow adhesive manufacturer's instructions.

Wall Application

- Apply adhesive to the wall (not the back of the fabric) and allow it to become tacky.
- Do not reverse hang panels.
- Hang panels in order they came off bolt.
- Do not stretch fabric or overwork the seams.
- When cornering, apply at least 6" (15 cm) around the corner.