


Outlet Box (VED), Voice and Data Box (VVD), Panel Mount Outlet Box Bracket (UNXBR)

NOTE: Single Sided Two Outlets Outlet Box (VED), Two Power Panel Mounted Bracket one Face Plate (UNXBR) shown.



NOTE: If over Horizontal Tube configuration is specified. Freestanding Foot and Power Box CAN NOT installed on the same side.
Double Box - Under Horizontal Tube shown as an example.

Part and Product Identification


	A1 -Outlet Box - Two Outlets (VED) x 1 OR - Outlet Box - Four Outlets (VED) x1 OR - Voice & Data Box (VVD) x1	
	A2 -#8 x 1 1/2" Pan Head, Quadrex (FS8-1 1/2PB) x2	
	A3 -Nylon Retaining Washer (WS-177-407) x4	
	UNXBR	B1 - Power Mount Outlet Bracket (UNXB2) x1 OR (UNXB4) x1
		B2 - Face Plate, Single (MPA15-E32) x1 OR - Face Plate, Double (MPA15-E34) x1 OR - Face Plate, Power/Data (MPA15-E33) x1
		B3 - 15/16-18 Hex Flange Locking Bolt (E03-0428) x2
		B4 - 15/16-18 Lock Nut, Zinc (E03-0437) x2

For Customer Support please contact
product.support@teknion.com

Section: **INTERNATIONAL ELECTRICS**


Description: **PANEL MOUNT OUTLET BOX BRACKET, OUTLET BOX INSTALLATION**

PANEL MOUNT BRACKET ADJUSTMENT




STEP 1: Bracket assembly differ depending on Panel Wall width. Refer to pages 5,6,7,8 and 9 to find out if adjustment is required.

SCREW CAPS REMOVAL



STEP 2: Remove plastic Screw Caps by pushing them from the rear of the Box.

OUTLET BOX INSTALLATION




STEP 3: Fasten Outlet Box to the Bracket using Washers and Screw Provided. **Refer** to pages 5 to 9 to find correct position. Push Screw Caps back in place.

Section: **INTERNATIONAL ELECTRICS**


Description: **PANEL MOUNT OUTLET BOX BRACKET, OUTLET BOX INSTALLATION**

RELOCATE BOLTS FROM ACCESSORY RAIL




STEP 4A: Slide Bolts in Accessory Rail to specified location for Power Box installation, and insert into Frame.
NOTE: If over Horizontal Tube configuration is specified. Freestanding Foot and Power Box CAN NOT be installed on the same side.

INSTALL ELECTRICS




STEP 5A: Bring Mounting Bracket with Outlet Box attached to the underside of the rail. Line up holes to maintain 4.5" dimension from face of the vertical rail to edge of Outlet Box. Secure assembly with Nuts from Accessory Rail.

BOTTOM RAIL INSTALLATION



STEP 4B: Line up holes of Bracket with holes on horizontal rail to maintain 5" distance between Outlet Box and vertical rail. Fasten with Bolts and Nuts provided.

INSTALLING HARNESS AND FASCIA




STEP 6: After making specified connections (Harness/Power/Data), install Fascias. For detailed instruction see Installation Guides # 201 and 202.

Section: **INTERNATIONAL ELECTRICS**


Description: **PANEL MOUNT OUTLET BOX BRACKET, OUTLET BOX INSTALLATION**

ABOVE WORKSURFACE, CENTRE




24", 36" WIDE PANEL WALLS ONLY

ABOVE WORKSURFACE, CENTRE




30" WIDE PANEL WALLS ONLY

BELOW WORKSURFACE, CENTRE



24", 36" WIDE PANEL WALLS ONLY

BELOW WORKSURFACE, CENTRE




30" WIDE PANEL WALLS ONLY

Section: **INTERNATIONAL ELECTRICS**


Description: **PANEL MOUNT OUTLET BOX BRACKET, OUTLET BOX INSTALLATION**

ABOVE WORKSURFACE, 2 OUTLETS, RIGHT SIDE




42", 48", 60", 66", 72", 78", 84", 90", 96" wide Panel Wall

ABOVE WORKSURFACE 4 OUTLETS, CENTRE




36" wide Panel Wall

BELOW WORKSURFACE, 2 OUTLETS, LEFT SIDE



42", 48", 60", 66", 72", 78", 84", 90", 96" wide Panel Wall

BELOW WORKSURFACE, 4 OUTLETS, CENTRE




36" wide Panel Wall

Section: **INTERNATIONAL ELECTRICS**


Description: **PANEL MOUNT OUTLET BOX BRACKET, OUTLET BOX INSTALLATION**

ABOVE WORKSURFACE 4 OUTLETS, L/R SIDE




42", 48", 60", 66", 78", 84", 90", 96" wide Panel Wall

ABOVE RAIL 4 OUTLETS, CENTRE




54", 72" wide Panel Wall

BELOW WORKSURFACE 4 OUTLETS L/R SIDE



42", 48", 60", 66", 78", 84", 90", 96" wide Panel Wall

BELOW WORKSURFACE 4 OUTLETS, CENTRE




54", 72" wide Panel Wall

Section: **INTERNATIONAL ELECTRICS**


Description: **PANEL MOUNT OUTLET BOX BRACKET, OUTLET BOX INSTALLATION**

ABOVE WORKSURFACE, CENTRED




36" WIDE PANEL WALL

ABOVE WORKSURFACE, CENTRED




54", 72" WIDE PANEL WALL

BELOW WORKSURFACE, CRNTRED



36" WIDE PANEL WALL

BELOW WORKSURFACE, CENTRED




36" WIDE PANEL WALL

Section: **NOTES**

Description: **PANEL MOUNT OUTLET BOX BRACKET, OUTLET BOX INSTALLATION**


ABOVE WORKSURFACE VOICE/DATA, L/R SIDE



42", 48", 60", 66", 78", 84", 90", 96" wide Panel Walls

NOTES

BELOW WORKSURFACE VOICE/DATA, L/R SIDE



42", 48", 60", 66", 78", 84", 90", 96" wide Panel Walls

NOTES