




### SEAT HEIGHT ADJUSTMENT




To raise the chair, lift the paddle up while lifting your weight from the seat until you reach the desired level and then release to lock in place. To lower the chair, lift the paddle up allowing your weight to push the seat down to the desired level and then release to lock in place.




### BACK TILT ADJUSTMENT




The tilt control paddle on the left locks the chair in four positions. To adjust the recline angle, push the paddle down to unlock it. Recline to the desired position and lift the paddle up to lock in place.




### ARM HEIGHT ADJUSTMENT




To adjust the arm height, press the small button on the outside of either arm to raise or lower it to the desired position. Release the button to lock in place.



### TENSION ADJUSTMENT




Lean back to determine if the resistance is comfortable. If it is too stiff, turn the knob counter-clockwise to decrease tension. If it does not provide enough resistance, turn the knob clockwise to increase tension.





### BACK HEIGHT ADJUSTMENT


The back height adjustment is activated by the chair's back. To adjust the lumbar height, lean forward and grasp both sides of the lower portion of the outside back. To raise, slide the back up. To lower, slide the back all the way to the top and then lower to desired height. Release to lock in place.




### ARM WIDTH ADJUSTMENT




To adjust the arm width push the lever down and slide the arm to the desired position. Push the lever up to lock the arm in place.




### STOOL HEIGHT ADJUSTMENT




To raise the chair, lift the paddle up while lifting your weight from the seat until you reach the desired level and then release to lock in place. To lower the chair, lift the paddle up allowing your weight to push the seat down to the desired level and then release to lock in place.



### STOOL FOOTRING HEIGHT ADJUSTMENT



To raise or lower the stool's foot ring, turn the foot ring's knob counter clockwise to release the foot ring and adjust the ring until you reach the desired level. Turn the knob clockwise to lock in place.



### ⚠ Warning

Tipping or collapsing can result in serious injury. To prevent product failure and possible injury:

- This chair has been designed and tested for users weighing up to 250 lbs
- Frequently inspect the chair for visible cracks and damages, tighten all screws, bolts, adjustable knobs and parts
- Do not use the chair if damaged or unstable – immediately remove it from service
- This chair is equipped with casters intended for use on carpeted surfaces. Use of these casters on hard surfaces could result in unexpected rolling and tipping. Casters designed for use on hard surfaces are available. If in doubt, see your dealer for appropriate selection
- Do not stand on or use the chair as a step ladder
- Failure to follow these warnings could result in serious injury