leverage Installation Guides

Section: PANEL CONNECTIONS AND TRIMS Description: THREE-WAY BRACKET FOR 30" HIGH PANEL 90 DEG INSTALLATION





leverage Installation Guides

Section: PANEL CONNECTIONS AND TRIMS Description: THREE-WAY BRACKET FOR 30" HIGH PANEL 90 DEG INSTALLATION

teknion Date: May 2020 Page No: 2 of 4 TLE_215a



STEP 1: Connect Panels together. Ensure Panels are leveled before locking Posi-Locks at any stage.



STEP 2: Install Glass Panel Add-On NOTE: Ensure Panel and Panel ADD-On are aligned properly before securing the Add-On to the Panel.

Leverage Installation Guides

Section: PANEL CONNECTIONS AND TRIMS Description: THREE-WAY BRACKET FOR 30" HIGH PANEL 90 DEG INSTALLATION



Date: May 2020 Page No: 3 of 4 TLE_215a



leverage Installation Guides

Section: PANEL CONNECTIONS AND TRIMS Description: TWO-WAY BRACKET FOR 30" HIGH PANEL 90 DEG INSTALLATION



